

2/13/2001 Jlab Ion Pump Controller Evaluation Meeting


Trip Report – J. Tang

The Goals of the meeting was


- Determine suitability of JLAB controllers for CCL/DTL/Ring & Transport Subsystems
- Review gauge and ion pump controller specifications
- Discuss turbopump station design

JLAB Ion Pump Power Supply and Its Control Card Overview by K. Jordan

Jlab Ion Pump Power Supply (5200 V 70 MA)



Jlab Ion Pump Control Card



Live JLAB Ion Pump Controllers for FEL at JLAB



Unique Capability Claimed

- All Analog: log amp provides 1.5 volts per decade output
 - Vacuum range $10\text{E}-10 \text{ torr} < P < 10\text{E}-6 \text{ torr}$
 - 1.5 volts per decade of vacuum change analog output
 - Allows for “slow” interlock at $3 \times 10\text{E}-9$ and “fast” response $1 \times 10\text{E}-7$
 - These trip levels are set in beamline and waveguide control cards
- Works for both RF and valve interlock
- Response time < 1 millisecond for 4 decades of vacuum change
- Start/Over current protection
 - 15 minute start full current then >10 milliamp trip
 - 70 mA start current
 - FET current surge bypass – log amp protection
- Full remote control
ON / OFF / Reset

400 IP PS in field (loss one per year) currently

\$600 - \$750 per ion pump ps (Not including control card)

Results of the meeting

- Ion Pump Controller Modifications
 - 200 mA, 10mA 100% duty
 - large ion pumps
 - log amp resolution
 - cold cathode control
 - Control through PLC vs Control Card
 - Check response time for PS at 10^{-7} Torr, 10^{-9} Torr
- Commercial Gauge Controller
 - Verify response time at 10^{-7} Torr
- TMPS Considerations
 - Include PIV in station control
 - Add manual valve I/O suitable
 - Standalone local control

SNS Vacuum Groups at JLAB, LANL and BNL will make the decision (What Ion Pump and Gauge Controllers will be used for SNS) in a month we hope.